Make sure you have all the latest information needed to use and enjoy this product! Visit ternbicycles.com/support for updated: MANUALS COMPATIBILITY ARTICLES VIDEOS & MORE

Weight Limits

A Do not exceed the load limit of 25 kg (55 lb).

Compatibility

Fits most Tern Link and Verge models, as well as select Vektron models. Visit <u>ternbicycles.com/support/compatibility-checker</u> for more on compatibility.

• Trolley Handle not compatible with certain models.

Depending on your model and configuration, some parts may need to be removed or modified, such as:

- Rear Fender Stays (replaced with Fender Hanger)
- Front and Rear Magnetix (may require removal)
- Rear Fender Spoiler (may require trimming)

Tools for Installation (Not Included)

Required Tools:


- 4 mm Allen Wrench with Ball End (for Rack Screws, Rack Stays, Pouch Screws)
- 5 mm Allen Wrench with Ball End (for Side Strut Fix Point)

Optional Tools You May Need:

- 6 mm Allen Wrench (for adjusting Trolley Wheel height)
- 8 mm Open Wrench (for installing Fender Hanger Nut)
- Pliers (for bending Fender Hanger)
- C-Retainer Ring Plier (for removing Magnetix)
- Scissors (for trimming Fender Spoiler)

What's Included

- Rapid Transit Rack x 1
- SideStrap x 1
- Mounting Hardware for Rack Installation
 - M5 x 15 Screw x 4
 - M5 Washer x 4
- Fender Hanger Kit
 - Fender Hanger x 1
 - M5 x 10 Bolt x 2
 - M5 Washer x 4
 - M5 Nut x 2
- Handle, Cover, and Pouch Kit
 - Handle x 1
 - Cover & Pouch x 1
 - M5 x 25 Screw x 2
 - M5 x 12 Washer x 2
 - M5 x 10 Washer x 2
 - 10 mm Spacer x 1
 - 5 mm Spacer x 1
- M8 Washer x 12






Rapid Transit Rack[™]

Mounting onto your Bike


Fender Hanger Installation

- Begin with this step if your bike is equipped with fenders.
- Skip this step if your bike is not equipped with fenders.

If your bike is equipped with fenders, the rear fender stays will be replaced by the Fender Hanger.




- 1. Place Hanger on the fender and mark the bend line.
- 2. Bend the Hanger with pliers.
- 3. The Hanger should hold onto the fender firmly without deforming the fender.




Rack Installation


▲ To better fit the location of the Frame Upper Bosses on different Tern bikes, mount the Front Stays either on the outside or inside of the Front Stay Fix Points.




- 1. Loosen the Top Deck Front Stay Fix Point Screws and rotate the Front Stay Fix Points to change the side on which the Front Stays are mounted. Choose the configuration that better fits your bike.
- 2. Set the Front Stay at the approximate required width. Tighten partially to allow for final adjustment.



3. Fix the Lower Mount to the Dropout Eyelets. Tighten partially to allow for final adjustment.




- 4. Fix the Front Stays to the Frame Upper bosses. Tighten partially to allow for final adjustment.
- 5. Level the rack and tighten all Mounting Screws (4 Nm).



6. If your bike is equipped with fenders, install the Fender Hanger onto the Rack Light Mount.

SideStrap Installation




- 1. Fold the Strap in half, thread it through the Top Deck Strap Loop and pass the Hook Ends through the loop to fix the Strap to the Top Deck
- 2. Wrap the Strap around the back of the Deck and fix the Hook Ends on the Main Stay.

Internal Cable Routing


If your bike uses wired rear light, route cable inside the left Side Strut (as seen from the back).

Pouch and Trolley Handle Installation


Install the parts as shown below. Trolley Handle is optional and does not fit all models, such as the Vektron.




Pouch-only installation.




Use 12 mm Washers inside.




For **Link** models, use the 10 mm and 5 mm Spacers.



Use 10 mm Washers inside and 12 mm Washers outside.



For $Verge \mod ls$, use a 5 mm Spacer.




Use 10 mm Washers inside and a 12 mm Washer outside.

Folding


Using the Secure Fold Strap

Your bike folds the same way as it did before.




Use the Secure Fold Strap to keep the bike folded securely by attaching it to the handlepost.


Positioning the Trolley Mode Seatpost



For models with a telescopic seatpost:

Lower the saddle all the way down.






For models with a single seatpost (non-telescopic): Lower the saddle so that it is adjacent to the handlepost joint. The seapost should not extend beyond the wheel.

Trolley Mode


Make sure all four Trolley Wheels contact the ground and that the bike can stand balanced.

Fender Spoiler Adjustment





If the fender spoiler contacts the ground, trim the spoiler with a pair of scissors.


Standing Angle Adjustment



Make sure all four Trolley wheels contact the ground. If all four Trolley Wheels contact the ground and the bike does not balance when being pushed, it is necessary to fine-tune the heights of the Trolley Wheels. The height of each wheel is independently adjustable.










- 1. Turn Trolley Wheel screw counter-clockwise and remove the wheel assembly.
- 2. Add M8 Washers (maximum 3 per wheel) as needed so that the bike is balanced when standing up and when being pushed in trolley mode.

Covering the Bike








Rapid Transit Rack[™]

Safety


- A Rapid Transit Rack is not designed for use with any kind of passenger seating accessories, including child seats.
- ⚠ The combined weight of the bike (including battery), rider, accessories, and cargo must NOT exceed the Maximum Gross Vehicle Weight (MGVW) indicated for your bike.
- A Make sure load weight is distributed evenly on both sides of the bike.
- $oldsymbol{\Lambda}$ Secure all cargo before riding. Take care that all Straps are tied down and any loose items are secured.
- A Check to ensure all accessories have been correctly installed and securely fastened before riding.
- A Your bike may behave differently with cargo.

Riding Off Curbs



A CAUTION: Be mindful to not ride off curbs. The trolley wheels can catch on the curb and damage the bike or injure the rider.

Straps



A For safety, the SideStrap must be fastened securely at all times to prevent interference with the wheels and drivetrain.

LIMITED PRODUCT WARRANTY INFORMATION: This Product comes with a ONE (1) YEAR Limited Warranty from the date of retail purchase by the original end-user. If a material or workmanship defect arises and a valid claim is received within the Warranty Period, this Product will be replaced. Mobility Holdings cannot be held liable for damages to personal property due to misuse or improper care and maintenance. This Product Warranty does not, under any circumstance, cover the replacement or cost of any third party product used with or connected to the Product.

Tern, the Tern Werd (logotype), the Tern Berd (device), and Rapid Transit Rack used alone or in combination are trade names, trade devices, or registered trademarks of Mobility Holdings, Ltd.

© 2025. Tern is a trademark of Mobility Holdings, Ltd. All Rights Reserved.

f @ ternbicycles

ternbicycles.com